Declaration of conformity

QUANTUM DESIGNS(HK) LTD.
5/F Somerset House, TaiKoo Place 979 Kings Road,
Quarry Bay, Hong Kong

declares that the product

Pentium®III Mainboard
Advance 5/133E

is in conformity with
(reference to the specification under which conformity is declared in accordance with 89/336 EEC-EMC Directive)

☑	EN 55022	Limits and methods of measurements of radio disturbance characteristics of information technology equipment
☑	EN 50081-1	Generic emission standard Part 1: Residential, commercial and light industry
☑	EN 50082-1	Generic immunity standard Part 1: Residential, commercial and light industry

European Representative:

QDI COMPUTER (UK) LTD	QDI COMPUTER (SCANDINAVIA) A/S
QDI SYSTEM HANDEL GMBH	QDI COMPUTER (NETHERLANDS) B. V.
QDI COMPUTER (FRANCE) SARL	QDI COMPUTER HANDELS GMBH
QDI COMPUTER (ESPANA) S.A.	QDI COMPUTER (SWEDEN) AB

Signature : _____ . Place / Date : HONG KONG/1999

Printed Name : Anders Cheung Position/ Title : President

Declaration of conformity

Trade Name:	QDI Computer (U. S . A.) Inc.
Model Name:	Advance 5/133E
Responsible Party:	QDI Computer (U. S. A.) Inc.
Address:	41456 Christy Street Fremont, CA 94538
Telephone:	(510) 668-4933
Facsimile:	(510) 668-4966
Equipment Classification:	FCC Class B Subassembly
Type of Product:	AGP Pentium®III Mainboard
Manufacturer:	**Quantum Designs (HK) Inc.**
Address:	5/F, Somerset House, TaiKoo Place 979 Kings Road, Quarry Bay, HONG KONG

Supplementary Information:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Signature : _____. Date : 1999

CONTENTS

SpeedEasy ¿ Ë Ù ¤ Ö Ä Ç ÏÖ Ê Ä Ì ä 1

SpeedEasy ¿ Ë Ù ¤ Ö Ä Ç ÏÖ Ê Ä ò ä 3

SpeedEasy Quick Setup(English) 5

SpeedEasy Schnell-Installation(Deutsch) 7

Fácil Y Veloz Rápida Instalación(Español) 9

Facilité de vitesse Initialisation(Francais) 11

Setup Della Scheda SpeedEasy(Italiano) 13

1. Introduction 15

Overview 15

Key Features 15

Introduction to New Features 18

2. Installation Instructions 19

External Connectors 19

PS/2 Keyboard & PS/2 Mouse Connector 19

USB1 & USB2 19

Parallel Port Connector and Serial Port Connector 19

ATX Power Supply Connector & Power Switch(POWER) 20

Hard Disk LED Connector (HD_LED) 20

Reset Switch (RESET) 20

Speaker Connector (SPEAKER) 20

Power LED Connector(PWR_LED) 20

Key_Lock Connector (KEY_L) 20

ACPI LED Connector (GREEN_LED) 21

Hardware Green Connector (SLEEP) 21

Infrared Header (IrDA) 21

Fan Connector (CPUFAN & CHSFAN) 22

Wake-Up On LAN (WOL) 22

Wake-Up On Internal Modem (WOM) 22

Chassis Security Switch (CHSSEC) 23

Sound Connector (PC-PCI) 23

Expansion Slots & I/O Ports description 23

Jumper Settings 24

Clear CMOS 24

Overclocking Jumper Setting(JFSB1, JFSB2, JCLK) 24

CONTENTS

Enable keyboard password power-on function(JKB) 25
BIOS-Protect Easy Jumper(JAV) 25

Memory Configuration 26

3. BIOS Description 27
Utility Support 27
AWDFLASH.EXE 27
AWARD BIOS Description 28
Entering Setup 28
Load Setup Defaults 28
Standard CMOS Setup 28
SpeedEasy CPU Setup 31
BIOS Features Setup 32
Chipset Features Setup 34
Power Management Setup 36
PNP/PCI Configuration Setup 38
Integrated Peripherals 40
System Monitor 42
Supervisor/User Password Setting 43
IDE HDD Auto Detection 44
Boot with BIOS defaults 45

Appendix A QDI Mainboard Utility CD-ROM 47
Appendix B Processor Installation Procedures 49
Appendix C Boot Logo 52

RecoveryEasy 49
Introducton 49
Operation Process 49
FAQ 54

SpeedEasy ¿ Ë Ù ¾ Ö Ä Ï

³ Ù ò

1. Õ ÿ µ Ø È Pentium®II, Pentium®III» ò Intel® Celeron™Ö Ñ ë À Æ ÷
2. ² È Æ È Å Ö Ã× é ³ É Ê ô Â ¢ Ü ú ¾
3. ¿ ¶ Ï ú ³ Ô ² ¢ × ÷ Del>¼ ü ½ È BIOS É Ö Ã Ù ò
4. ½ È ë "SpeedEasy CPU SETUP" ² ¤ ¥ Ò Ô ½ Ö Ñ ë À Æ µ Ä Ù È

× Ò âÈ ê µ ½ Ö Ñ ë À Æ µ Ä Ù È Ï ú ½ ò Ô é ¶ ¤ ü Ä Ù È Ö È Ð ¶ Ô ý Ü Æ Â Ê ª 100MHz µ ÄCPU, Î ª 200MHz ; ¶ Ô ý Ü Æ Â Ê ª 66MHz µ ÄCPU, Î ª 133MHz, ¶ Ô Ú ± ¶ Ê ÿ È À ÄPU, Ô È Æ È µ Ê Ù È

5. ´ æ É ¶ Ö µ Í Ë BIOS, Ï ú ¾ Ï È Ô Ä É ¶ ü Ä Ù È È Ä È

SpeedEasy Ö Ñ ë À Æ É ¶ ² Ë ¥

´ Ö É Ö Ã Ë Ö Ñ Ô ñ<SpeedEasy CPU SETUP>Ï î È á ¼ è ë Î Ë ¥

Í ¼ 1 SpeedEasy Ö Ñ ë À Æ É ¶ Ï Ã µ ¥

BIOS Î Ä ã Ä Ñ ë À Æ Ì á Ò » ó ù Ñ Ï î Ò Ô Ù æ ¼ ß Ã Ö (Jumper) · Ê½ Ê ¹ Ä ã Ö Ô ÚSpeedEasy CPU SETUP" ² Ë É Ï Î Ö Ñ ë À Æ Ñ Ô Ñ Ý µ Ä ¤ Æ µ Â Ê

¾ ¯ æ

Ç Ê Ø Ö Ñ ë À Æ µ Ä Â Ê ½ Ñ Á SS ¶ Ñ ÿ £ ¤ Æ Â Ê · Ô ò ¾ Ë ¾ « ² » á Ô Ó É ¶ Ø É ú Ä Î Ê ð Ù

SpeedEasy¿ Ë Ù × Ö Ä Ï

³ Ù ò

1. Õ ÿ µ Ø È ëPentium®II, Pentium®III » ò ntel® Celeron™ Ö Ñ ê À Æ ÷
2. ² È Æ Ë Å Ö Ã × é ³ É Ê Ô Â ¢ ü µ ³
3. ¿ Æ ö µ ³ Ô ´ ² Ç Ò × ÷ <Del>¼ ü ½ È BIOS É Ö Ã Ù ò
4. ½ È ë"SpeedEasy CPU SETUP" ² ¥ Ò Ô ½ Ö Ñ ê À Æ µ Ä Ù È

× ò â È ê µ ½ Ö Ñ ê À Æ µ Ä Ù È Ï µ ½ ò Ô é µ Ä Ù È Ö Ö ð 100 Ö × Ö Ü Ï ß ÄCPU » à Ô 200 Ö × Ö Ö Ð 66 Ö × Ö Ü ß ÄCPU » à Ô 133 Ö × Ö Ö Ð ¶ Ô Ó ü ¾ ß ÿ Ö à ÄCPU， Ô Ö Ø È µ Ê Ù È。

5. ´ æ É ¶ Ö µ Í Ë BIOS，Ï µ ¾ ¿ Ö Ô Ä É ¶ ü Ä Ù Ö Ö Á Ë

SpeedEasy Ö ñ ë À Æ É ¶ ² ¤ ¥

´ Ö É ö Ã ¤ ö ñ ¶ ñSpeedEasy CPU SETUP> Ï î È á ½ è ë Ó ¤ ¥

Í ¼ 1 SpeedEasyÖ ñ ë À Æ É ¶ Ï Ã µ ¥

BIOSÎ Ä ã Ø ñ ë À Æ È á Ò » é ù Ñ Ï î Ò Ô Ù æ ¿ ¤ Ã ö (Jumper) · Ê½Ê ¹ Ä ã ö Ô ÚSpeedEasy CPU SETUP" ² ¤ É Ï Î ö ñ ë À Æ Ñ ¶ Ö ÿ µ Ä ¤ Æ Ê Ê

¾ ¯ æ

Ç ê ½ Ö ñ ë À Æ µ Ä Ê Ê ½ Ö Á ß ¶ ê ÿ £ ¤ Æ Ê Ê · Ô è ¾ Ë ¾ « » á Ô ð Ó É ¶ ø É µ Ã Ï Ê ð Ù

SpeedEasy Quick Setup

Procedures :

1. Correctly insert the Intel Pentium®II/ Pentium®III/ Celeron™processor.

2. Plug in other configurations and restore the system.

3. Switch on power to the system and press the <Del> key to enter BIOS Setup.

4. Enter "SpeedEasy CPU SETUP" menu to set up the CPU speed.

Note: If you do not set the CPU speed, your system will run at the default setting (200MHz for processor with 100MHz host bus speed, 133MHz for processor with 66MHz host bus speed, for bus ratio locked processor, run its real speed.

5. Save and exit BIOS Setup, your system will now boot successfully.

SpeedEasy CPU Setup Menu

Select <SpeedEasy CPU SETUP> item from the main menu and enter the sub-menu:

Figure - 1 SpeedEasy CPU Setup Menu

BIOS provides you with a set of basic values for your processor selection instead of the jumper settings. The processor speed can be manually selected on the "SpeedEasy CPU SETUP" menu screen.

Warning:

Dot not set CPU frequency higher than its working frequency. If you do, we will not be responsible for any damages caused.