



GENERAL NOTES

1. REMOVE AND DISPOSE OF COLD MIX ASPHALT OVER TRENCH.
2. EXCAVATE CRUSHED ROCK TO BELOW EXISTING ROAD SURFACE AND RE-COMPACT CRUSHED ROCK BELOW.
3. TACK COAT EDGES OF TRENCH.
4. SUPPLY & LAY BITUMINOUS CONCRETE IN LAYER AS DETAILED.
5. HEAT EDGES OF TRENCH (WITH BLOW TORCH) WHEN LAYING WEARING COARSE ASPHALT.
6. SAW CUT THE TRENCH IF REQUIRED BY THE SUPERVISING ENGINEER. THIS IS A VARIATION TO THIS CONTRACT ITEM.
7. TRAFFIC CONTROL MUST BE PROVIDED FOR THESE WORKS IN RESIDENTIAL STREETS.
8. TRAFFIC CONTROL ON MAIN ROADS IS TO BE NEGOTIATED WITH THE SUPERVISING ENGINEER AND IS VARIATION TO THIS CONTRACT ITEM.